

# *Stratos*<sup>®</sup> *Nano*

## Installer's Handbook



*LM80031 Issue H*



0832

Kidde Products Limited

Unit 2 Blair Way

Dawdon

City: Seaham, County Durham

SR7 7PP UK

09

0832-CPD-1312

EN 54-20:2006

Aspirating smoke detectors  
for fire detection and firealarm  
systems for buildings

Class A, B and C

## Index

Introduction	Page 3
Outside the Detector	Page 4
Inside the Detector	Page 5
Installation: Mechanical	Page 6
Installation: Printable A4 Drill Template	Page 7
Installation: Electrical	Page 8
Installation: Sampling Pipe	Page 9
Configuration	Page 10
Commissioning	Page 11
Maintenance	Page 12
Troubleshooting	Page 13
Optional: Communications Card	Page 14
Technical Data & EN54-20 Compliance	Page 15/16

## Introduction

This aspirating smoke detector is designed to provide reliable performance in a variety of environment and to ensure that installation and commissioning are as simple as possible. An aspirating smoke detector uses a fan to draw samples of air from a network of pipes with sampling holes positioned as if they were point smoke detectors.

The detector incorporates a patented artificial intelligence system which allows the detector to adjust itself to the optimum sensitivity for any environment.

The artificial intelligence system also monitors the detector chamber and air filter, and automatically compensates for contamination. This provides a stable response and signals a fault if the contamination reaches a level that cannot be compensated for.

---

This smoke detector is Class III as defined in EN60950. It is designed to operate from Safety Extra Low Voltages and does not generate any hazardous voltages.

---

If this detector is to form part of an approved fire detection system, its power must be supplied from a certified power supply (typically EN 54-4).

---

In order for the installation to conform to EN 54-20, pipes must conform at least to EN 61386-1 Class 1131.



Please note that printed circuit boards are static sensitive and must not be handled without taking proper static precautions.



The detector is a Class 1 laser product as defined in IEC 60825-1. This unit incorporates a Class 3B embedded laser which must not be removed from the detector, as retinal damage may occur if the beam enters the eye.


---

*Every care has been taken to ensure that the detector is as easy to install as possible by trained fire alarm engineers. In case of difficulty, please contact the Help Line in the first instance to ensure trouble free installation and operation.*

**POŠUŠO OKEI | AEDF | I | EG | EE | A**

*The manufacturer takes no responsibility for damage or injury occasioned as a result of failing to install or operate or maintain the equipment in accordance with these instructions and other good practices.*

## Outside the Detector




1. **Front Cover Securing Screw:** leave sufficient clearance below the detector to allow screwdriver access to this screw.
2. **Fire Alarm:** illuminates to indicate that the smoke level has passed the detector's Fire 1 threshold, and the normally open FIRE relay contacts have closed.
3. **Pre-Alarm:** illuminates to indicate that the smoke level has passed the detector's Pre-Alarm threshold, and the normally open PRE-ALARM relay contacts have closed.
4. **Fault:** illuminates to indicate a fault condition and that the normally closed FAULT relay contacts have opened. Three additional LEDs indicate the type of fault:
  - a) **Flow:** illuminates to indicate an airflow fault. This may be due to blocked or broken pipes, although it can also occur if, for example, factory warehouse doors are opened on a windy day, or if industrial air conditioning turns on. Another possible cause is that the aspirating fan connection cable is damaged or disconnected.
  - b) **Filter:** illuminates to indicate that the detector's air filter needs to be changed.
  - c) **Head:** illuminates to indicate a problem with the detector laser chamber, as might be caused by the laser head connecting cable is damaged or disconnected. It can also be caused by certain kinds of internal systems faults, which appear in the detector's event log as "process errors".

*NB: if the FAULT LED is illuminated but none of the additional LEDs are lit, it indicates a problem with the power supply if its fault output is connected to the detector's INPUT terminals.*

5. **OK:** illuminates to confirm normal operation.  
*NB: during initial setup, the OK LED will flash for 15 minutes while the detector learns its operating environment. This does not indicate a problem with the detector.*

## Inside the Detector



1. **Aspirating Fan Connector Lead:** If this lead is broken or not connected, the fan will not turn and the detector will indicate a FLOW fault.
2. **Main PCB:** No user-serviceable parts. *NB: The PCB is fixed in place with 5 off M3 x 6 screws. The detector must not be operated with any of the screws missing, as this may cause air leaks and unreliable operation.*
3. **DIL switch:** used to configure user-selectable detector functions
4. **Detector Head Ribbon Connector:** If this lead is broken or not connected, the detector will indicate a HEAD fault.
5. **Detector Head Cover Plate.** This protects the laser head. The plate should not be removed from the detector.
6. **Detector Head Assembly:** No user-serviceable parts. Do not remove this from the detector due to the risk of exposure to the laser.
7. **Replaceable Dust Filter:** This simply slides in and out of its mounting. The filter and its replacement have IN written in red on one side, and OUT on the other to allow correct orientation. The part number for ordering spare dust filters is 30755. *NB: as viewed above, IN should be on the left and OUT should be on the right, as indicated by the moulded-in arrows next to the filter slot.*

## Installation: Mechanical


### Cable Entries

- 2x 20mm Conduit Holes, e.g for 20mm packing glands.
- Drilling guides are provided for drilling two additional 2x 20mm holes in the top and 1x 20mm hole in the bottom if needed.

### Pipe Entries

- 3/4" ABS Pipe.
- Use a 3/3" male to 25mm female adaptor (e.g. Manufacturer part no. 10952) if 25mm pipe is used.

*NB: Do not glue pipes into detector to facilitate future removal.*




### Fixing Holes (3 x M5 x 13 slots)


- Refer to printable drilling template on next page for accurate positioning

*NB: Ensure the detector is fixed to a flat surface – otherwise the enclosure will twist.*

## Installation: Printable A4 Drilling Template



## Installation: Electrical



In accordance with good wiring practice, keep cables and individual bared conductors as short as possible while allowing stress-relieving cable forming.

Power cables should be screened and current-rated at 1A or greater. Signal cable should be 120Ω screened twisted pair, such as Belden 9841 24AWG.

\*The INPUT terminals are set by default to monitor the power supply. If power supply monitoring and ClassiFire Override are not required, fit a wire link across the two terminals to prevent a fault condition on power-up.




## Installation: Pipework

### Sampling pipe

- 3/4" pipe or 25mm pipe with a 3/4" sleeve adapter.
- The maximum sampling pipe length is 50m.
- Fit an end cap with an appropriately-sized hole to optimize airflow through the pipe. This end cap hole is also a sampling hole.
- Do not glue the pipe into the sampling inlet.

### Exhaust pipe

- 3/4" pipe or 25mm pipe with a 3/4" sleeve adapter.
- If the protected area is at a lower atmospheric pressure than the location in which the detector is installed (e.g. a closed air-conditioned room), fit a return pipe run from the detector exhaust to the protected area, in order to equalise the pressure. This will improve detector response.
- Even if the protected area and detector are at the same atmospheric pressure, it is good practice to fit a pipe stub with a bend to the exhaust, to prevent debris falling into the detector.
- Do not glue the pipe into the exhaust outlet.



## Configuration

Configuration is carried out via the DIL switch mounted on the Main PCB.

	Switch 1	Switch 2	Switch 3	Switch 4	Switch 5	Switch 6	Switch 7	Switch 8
<b>Set Detector Sensitivity</b>								
Alarm Factor 6	Off	Off						
Alarm Factor 7	On	Off						
Alarm Factor 8	Off	On						
Alarm Factor 9	On	On						
<b>ClassiFire On</b>			Off					
<b>Fixed Alarms</b>			On					
<b>Flow Limit Offset</b>								
±40				Off	Off			
±20				On	Off			
±5				Off	On			
±3				On	On			
<b>Flow Delay</b>								
240sec						Off		
30sec						On		
<b>Input Select</b>								
PSU Fault							Off	
ClassiFire Override							On	
<b>Auto Calibration</b>								
Enable								Off
Disable								On

**NB:** Denotes EN 54-20 test configuration (factory default) settings

**Alarm Factor:** the detector calculates sensitivity relative to the ambient pollution level. Higher Alarm Factors provide reduced sensitivity (the alarm threshold is maintained further away from the ambient level). Refer to the remote software manual for further details. *NB: Changing the Alarm Factor starts a new FastLearn cycle: during the initial 15 minute learning period, the detector is incapable of reporting an alarm, and will take 24 hours to achieve optimum performance, based on the ambient conditions.*

**ClassiFire® On:** allows the artificial intelligence system to continuously adjust alarm thresholds in order to avoid unwanted alarms from environmental changes (recommended). *NB: Disabling this feature means that nuisance alarms due to fluctuations in ambient pollution levels become more likely.*

**Fixed Alarms:** switches the artificial intelligence system off, locking sensitivity to that set at initial setup. This de-activates the dust filter monitoring system (not recommended). *NB: Enabling this feature means that nuisance alarms due to fluctuations in ambient pollution levels become more likely.*

**Flow Limit Offset:** sets the sensitivity of the airflow monitoring system. A small offset makes the system very sensitive to air flow changes. EN 54 systems must react to ±20% changes in airflow, which equates to a change in flow sensor reading of ±5. Areas with fluctuating air pressures may require a less sensitive setting. *NB: Changing the flow limit offset starts a new flow calibration set up.*


**Flow Delay:** sets the time for which a flow fault must continue before a fault is signalled.

**Input Select:** the detector input terminal may be used to either monitor an associated power supply for faults, or for ClassiFire® Override (reduces normal sensitivity by 50%). *NB: in the factory default condition, the switch is set to OFF (power supply monitoring). This will give a fault condition if there is an open circuit on the INPUT terminals, so fit a wire link if power supply monitoring is not required. If a wire link is fitted across the INPUT terminals, it is important that this switch be set to OFF, since otherwise the detector sensitivity will be dramatically and permanently reduced by the ClassiFire Override function.*

**Auto Calibration:** automatically starts a new FastLearn cycle when the detector is powered up. This may be disabled if the previous settings need to be retained.


## Commissioning

Local standards and specification requirements must be adhered to. A typical commissioning procedure might entail the following steps:



## Maintenance

Local standards and specification requirements must be adhered to. A typical maintenance procedure could entail the following steps:



### Notes:

- *It is prudent to disconnect or isolate the detector from the fire panel during maintenance to prevent unintentional alarm activations.*
- *The detector should be powered down during internal cleaning (use an air duster can or dry air gun).*

## Troubleshooting

### Nuisance alarms:

- This normally indicates that the detector is set at an Alarm Factor inappropriate to the installed environment.  
*Increase the Alarm Factor to reduce sensitivity.*
- The sensor chamber may be contaminated.  
*Return the sensor chamber for factory cleaning and recalibration.*

### Detector will not pass smoke a test:

- Detector may be in a FastLearn cycle.  
*Check green OK LED is not flashing.*
- The detector FastLearn cycle may have been carried out during or immediately after smoke tests.  
*Reinitiate FastLearn with the detector in a clean environment.*
- The Alarm Factor is too high.  
*Change the Alarm Factor to a lower, more sensitive, setting.*


### Nuisance flow faults:

- Flow monitoring is too sensitive for the environment.  
*Increase the flow limit offset.*
- Airflow may be subject to temporary changes (spikes).  
*Increase flow delay.*

### Long transport times:

- Sampling pipe may be too long or have too many sampling holes/capillaries or incorrect hole sizes.  
*Check design with pipe modelling software.*
- Sampling pipes, sampling holes and/or the exhaust pipe may be partially blocked by dust or debris.  
*Clean pipe work with dry compressed air and/or clean the sampling holes.*
- Fan may be defective.  
*Send detector for repair.*
- Fan lead may be disconnected  
*Reconnect lead.*

## Optional: Communications Card



**Board locating post**

**Detector address DIP switch**

- The detector address is set using a reverse binary code, i.e. switch 1 is the least significant bit and switch 8 is not used.
- Set to address from 001 to 127 in order to identify the detector to the remote control software

**2 off M3 x 6 fixing screws**


- Provided with board.

**RS-232 serial port**

- Use 9-pin D-type null modem cable to connect to PC

A Communications Card may be fitted inside the detector.

Direct connection of a PC to the Communications Card is via a 9-pin RS-232 interface on the Communications Card, using a Null Modem cable configuration, as shown in the diagram below.



A connected PC may access the detector event memory to review previous or current events such as detector sensitivity. The detector internal Chart Recorder may also be accessed for analysis of detector behaviour (see separate Remote Software Manual for further information). The PC cannot be used to configure the detector except to enter time and date settings for the detector event log and chart recording to be viewed in the Remote Software. The detector does not incorporate a real time clock, so the time and date need to be re-entered if the detector is powered down for any reason.

Installation of the Communications Card also provides the detector with RS-485 network communication via the A, B and SCREEN terminals on the detector main board. This can be used for simple remote display indication or integration into a larger site wide management and display system, separate from the local Fire Detection and Alarm system connection. The Communications Card has short circuit bus isolation but does not have an RS485 repeater

## Technical Data

SELV Rating.....	EN 60950 Class III
Supply Voltage.....	21.6v – 26.4v DC
Current Consumption.....	350mA
Electrical Safety.....	Complies with EN 610190-1
Size (mm).....	190w x 230h x 110d
Weight.....	1.2kg
Operating Temperature Range.....	0°C to 38°C (UL 268) -10°C to 60°C (EN 54-20)
Operating Humidity Range.....	0 to 90% Relative Humidity, Non-Condensing EN61010-1 Pollution Degree 1 EN61010-1 Installation Category II
IP Rating.....	IP50
Sensitivity Range.....	0.4% to 25% obscuration/metre
Detection Principle.....	Laser Light Forward Scattering Mass Detection
Maximum Number of Sampling Holes.....	Class A: 2 Class B: 4 Class C: 10
Maximum Sampling Pipe Length.....	50m
Sampling Pipe Inlets.....	2 off ¾" pipe inlets (sampling pipe and exhaust)
Alarm / Fault Relays.....	Pre-Alarm / Fire / Fault
Relay Contact Rating (Changeover).....	1A @24V DC resistive load
Programming.....	Internal DIL Switches
PC Interrogation.....	Via optional Communications Card
APIC Compatible.....	Yes

### Notes:

- *Some devices such as sounders and beacons have high inrush currents on activation, which can damage relay contacts. It is good practice to consider fitting a suitable current limiting resistor in series with the load to avoid this potential problem.*

## EN54-20 Compliance

The installation must be designed using PipeCAD software, which is provided free on the CD shipped with each detector. After designing the installation including pipes, endcaps and sampling holes, enter the detector type. To select the detector type, select Options, select Calculation options, and then select the detector from the Type drop-down list.

Select "Options" "Calculate" or click on the calculator icon. The software will prompt you to choose from "Use set hole sizes" "Best flow balance" and "Max. permissible transit time". Select the appropriate option and click "OK". The results for each pipe ("View" "Results") show calculations for each sampling hole on the pipe with the nearest to the detector at the top of the screen, and the endcap hole at the bottom.

The classification of each sampling device configuration and associated sensitivity settings are determined by the column headed "Hole sensitivity % obs/m" which shows the predicted sensitivity for each hole. For the installation to comply with EN54-20 depending on the class of installation, each sampling hole must be no less sensitive than the following:

Class A: 0.80% obs/m

Class B: 1.66% obs/m

Class C: 5.85% obs/m

The calculation can be further refined by leaving a working detector in the protected area for at least 24hrs at the intended alarm factor for the installation (this could be done before or after installation). The detector sensitivity can be read from the "Sensitivity" figure on the histogram screen of the Remote software supplied with each detector. Click "Options" and then click "Calculation options" to open the "Hole calculation options" dialog box. Enter the sensitivity value obtained from the practical test, and then click OK. The new calculated value will use the the real sensitivity from the practical test.

The PipeCAD software will determine the classification of any used configuration. Commissioning and periodic system tests must involve smoke tests to verify that the system performs as expected and enters Fire 1 alarm within the time determined by PipeCAD from the farthest hole. The detector sensitivity must also be inspected to ensure it has not radically fallen from the installed figure. If it has changed for any reason, the new figure must be re-entered into PipeCAD and the recalculated hole sensitivities must be confirmed to be within the class limits shown above.